

Table of Contents

Overview of How the Controller Functions	2
<i>The Keypad</i>	<i>3</i>
Getting Started	4
<i>Testing and Recording</i>	<i>4</i>
<i>Room Temperature and Humidity</i>	<i>4</i>
<i>IdLE and CPL Messages</i>	<i>4</i>
<i>Which Instructions to Use</i>	<i>4</i>
<i>How to Tell if You Have Cone-Fire</i>	<i>4</i>
<i>Care of the Thermocouple</i>	<i>4</i>
<i>Display Dots</i>	<i>4</i>
Single Center Dot: Time	4
Single Right-Hand Dot: °C	4
Three Dot Display: Power Monitoring	4
<i>Correcting Entries</i>	<i>5</i>
<i>The Stop Key</i>	<i>5</i>
<i>Cool-Down Temperature Display</i>	<i>5</i>
<i>Repeat Firings</i>	<i>5</i>
<i>Program Review</i>	<i>5</i>
<i>Pyrometric Witness Cones in Ceramic Firings</i>	<i>5</i>
<i>When Kiln Shuts Off Too Soon</i>	<i>5</i>
Ceramic Cone-Fire	5
<i>Cone-Fire Basics</i>	<i>5</i>
Firing Speeds	5
Hold	6
Pre-Heating the Ware	7
AOP	7
<i>Advanced Cone-Fire</i>	<i>7</i>
Built-in Cone Table	7
Firing History in Cone-Fire	7
Fine-Tuning Shelf Cones With Cone Offset (CnoS)	7
Ramp-Hold	8
<i>Ramp-Hold Basics</i>	<i>8</i>

User Programs	8
Segments	8
Rate	8
Hold	8
AOP	9
<i>Advanced Ramp-Hold</i>	<i>9</i>
Segments for Controlled Cooling	9
Skip Segment	9
16 Segment Firing (16-S)	9
Additional Features	10
<i>Selecting °F or °C (CHG 9)</i>	<i>10</i>
<i>Delay Fire</i>	<i>10</i>
<i>Temperature Alarm</i>	<i>10</i>
Setting the Alarm From Idle	10
Setting Alarm During Firing	10
<i>Add Time</i>	<i>11</i>
<i>Present Status: Current Segment and Circuit Board Temperature</i>	<i>11</i>
<i>Checking Circuit Board Temperature from IdLE</i>	<i>11</i>
<i>Power Failures</i>	<i>11</i>
Firing Ceramics After an Extended Power Failure	11
<i>Thermocouple Offset (tCOS)</i>	<i>11</i>
<i>Thermocouple Offset for Ceramic Firings</i>	<i>12</i>
Calibrating Thermocouple Offset with a Thermocouple Standard or Pyrometer	12
Setting Thermocouple Offset	12
<i>Turning Off Error Codes (ErCd)</i>	<i>12</i>
Setting Error Codes ON or OFF	12
RTC 1000 Cone-Fire Quick Reference	13
RTC 1000 Ramp-Hold Quick Reference	14
Appendix A: Edit-on-the-Fly	15
<i>Programming</i>	<i>15</i>
Programming Cautions	16

Precautions

The controller is used to control temperature; it is not a safety device.

Do not operate the controller in temperatures above 125 °F.

Never leave your kiln unattended at the end of a firing.

The controller contains electronic components that are sensitive to static electricity. Before handling the controller dissipate any static charge you may have by touching metal or a screw on the controller panel, the electrical box, the kiln lid, or some other grounded object.

Always check the position of the thermocouple probe before starting a firing. The current temperature displayed on the controller is measured at the end of the thermocouple.


Always review the current program before firing to ensure the correct profile is programmed.

Overview of How the Controller Functions

You enter a program that tells the controller what temperature you want to fire to and at what rate you want the temperature to rise. The controller uses a thermocouple (t/c) to sense the temperature of the kiln. The temperature is measured at the tip of the t/c. When “start” is pressed, the controller reads the kiln temperature and uses that temperature as a starting point for a traveling set point. The controller then calculates how much power is needed to keep the temperature equal to the traveling set point and cycles the electricity to the elements so the correct amount of power is applied. As the firing progresses, the controller moves the traveling set point according to the programmed firing rate and recalculates how much power is needed to keep the temperature at the new traveling set point.

You can enter a program in two different ways. The cone fire method is the easiest and is designed for firing ceramics to ensure correct heat-work for each cone number and firing rate. With as few as six key presses, you can have a firing programmed and started. The ramp-hold method allows more complicated profiles and freedom but is slightly more difficult to program. Ramp-hold programs are used for firing such things as glass, jewelry, and crystalline glazes.

RTC 1000



The Keypad

The controller is easy to master once you understand that the keys have two functions:

1. Select and Operation

Press a key to start the operation shown in the top half of the key. Most operations begin by pressing **START** from **IdLE** display. Some operations begin during firing.

2. Type Numbers

After beginning an operation, press keys to enter numbers, such as time and temperature.

Getting Started

Do NOT fire your kiln or furnace until you have read this section and "Cone-Fire Basics" or "Ramp-Hold Basics". To use your controller to its fullest capacity, read the advanced sections and "Additional Features".

Testing and Recording

You will learn much by testing. How slowly should clay be heated through quartz inversion? How slowly must you cool glass through the annealing range? Find out for yourself by testing. The RTC 1000 can precisely control every stage of firing, so you can easily experiment and test.

Keep a notebook of firing records. When you fire similar projects weeks later, after you have forgotten the details of your previous firing, you will be grateful for your records.

Room Temperature and Humidity

It is okay to store the RTC 1000 at subzero temperatures. But before operating, raise the room temperature to at least 0°F/-18°C.

The circuit board is rated for 155°F/68°C maximum operating temperature. However, maximum temperature for rated accuracy is 125°F/52°C. If the board gets hotter, open windows and exhaust hot air from the room. (See page 8 for instructions on checking circuit board temperatures.)

High humidity will not adversely affect the RTC 1000 unless water condenses on the circuit board. If this happens, do not fire the kiln until the moisture has evaporated from the board.

IdLE and CPL Messages

The controller displays **ErrP** when you first apply power. Press **ENTER**. **ErrP** will change to **IdLE** and a flashing temperature. Operations begin from **IdLE**.

If the display shows **FAIL** instead of **IdLE**, the thermocouple is either disconnected or burned out.

CPL means "completed". The controller will display **CPL**, then **IdLE**, after it performs such actions as changing from °F to °C display. **CPL** may remain after a while before **IdLE** appears. Please be patient ---the controller is processing data.

Which Instructions to Use

The RTC 1000 fires in two modes

1. **Ceramic Cone-Fire**, based on pyrometric cones
2. **Ramp-Hold**, based on firing rates and target temperatures.

Ceramic kilns, usually top-loading, use both Cone-Fire and Ramp-Hold. Heat-treating, glass fusing, and enameling furnaces and kilns usually come with ramp-hold only.

How to Tell if You Have Cone-Fire

1. From **IdLE** display, press **ENTER** then **1**. If **ConE** appears, you have Cone-Fire mode. If **----** appears, you have Ramp-Hold mode only.
2. Bring the controller back to **IdLE** display:
 - a) From **----**, press **STOP**. **IdLE** will appear.
 - b) From **ConE**, press **ENTER** 3 times slowly. **CPL**, then **IdLE** will appear.

If you have Cone-Fire, this entire manual applies to your controller. If you have Ramp-Hold only, you may skip to page 5.

Care of the Thermocouple

The small metal rod protruding into the firing chamber is the temperature sensor, or thermocouple. Do not let shelves, posts, or ware touch the thermocouple; this could affect the temperature reading.

Bumping the thermocouple during loading can damage it or push it out of the firing chamber. It should protrude into the firing chamber at least 1-1/2" to 2".

Avoid firing clay with high sulfur content. The sulfur erodes the thermocouple making it brittle and easy to break.

Display Dots

Single Center Dot: Time

A lower center dot appears during time display. It separates hours from minutes (i.e. 1 hour, 30 minutes displays as 1.30). During temperature display, the dot disappears.

Single Right-Hand Dot: °C

When a temperature is displayed in °C, a lighted dot appears in the lower right. In °F it disappears.

Three Dot Display: Power Monitoring

To adjust temperature, the RTC 1000 sends power to the relay(s) intermittently. The relays, in turn, power the heating elements. To monitor when the relays are turned on, press **8** during firing. When three dots appear along the bottom display, relays are receiving power.

To turn off Power Monitoring, press **8** again. This feature is used mostly for diagnostics.

Correcting Entries

If you enter the wrong temperature, cone, time, etc., while programming, enter 0000. Then enter the correct numbers before pressing **ENTER**.

The Stop Key

You can stop a firing at any time by pressing the **STOP** button.

If you inadvertently enter Ramp-Hold, you do not have to go through all the prompts to get back out. Press **STOP** when **USER** appears. That will take you back to **IdLE**.

If you inadvertently enter Cone-Fire, **STOP** will NOT take you back to **IdLE**. Press **ENTER** after each Cone-Fire prompt until **CPL**, then **IdLE** appears.

If you inadvertently press **MENU**, you can get back to **IdLE** by pressing **STOP**.

Cool-Down Temperature Display

When the firing is finished **CPLt** will display alternating with the total firing time in hours and minutes. To view the current kiln temperature as the kiln cools, press **ENTER**. **CPLt** will disappear. Then temperature will display.

Repeat Firings

To repeat the previous firing, press **ENTER** twice from **IdLE**. The kiln will begin firing. This works in both Cone-Fire and Ramp-Hold. But first, make sure you are repeating the correct firing by using "Program Review" below.

Program Review

When you select a firing program in Cone-Fire or Ramp Hold and go back to **IdLE**, you have called a program from storage. It is then ready to fire. "Program Review" shows you the values for that program.

To start "Program Review" from **IdLE**, press **ENTER**, then **6**. Values for the program selected for firing will display one after the other. You can also use Program Review during firing simply by pressing **6**.

***TIP:** In Program Review, values for a program display about one per second. You can speed up this display by pressing **1** repeatedly. If you hold down the key, the values will speed by. This works from both **IdLE** and during firing.*

Pyrometric Witness Cones in Ceramic Firings

Though the RTC 1000 fires electronically, every ceramic firing should include shelf or witness cones. They measure heat work accurately and give a history of the firing.

If you fire the same sized load and type of ware regularly, the shelf cones let you compare one firing to the next and alert you when something is wrong. For example, if the shelf cone bends farther and farther with each consecutive firing, this may indicate thermocouple temperature drift.

Keep cones 3" from the peephole to avoid cool air drafts. Wear firing safety glasses when viewing the cones at high temperature. Your dealer can tell you which cone number to use for each clay and glaze.

When Kiln Shuts Off Too Soon

If the kiln shuts off below maturity, you can turn it back on and keep firing. Simply program a higher temperature or hotter cone. Then from **IdLE**, press **START** twice. The kiln will begin firing, taking up where it left off.

Ceramic firings: if the kiln shuts off within 100°F/50°C of maturity, and the temperature drops 50°F/28°C or more after the kiln shuts off, do not depend on the pyrometric witness cones in the kiln. Once the cones cool 50°F/28°C after they have been heated within 100°F/50°C of maturity they will not bend properly. This is due to the formation of a hard shell.

Ceramic Cone-Fire

Cone-Fire mode is based on pyrometric cones. It is not designed for heat-treating, glass fusing and enameling. For these firings, see "Ramp Hold", page 5. Use Ramp-Hold to fire ceramic pieces that require a custom firing schedule, such as some types of stoneware sculpture or crystalline glaze. To fire faster than Cone-Fire Fast speed, use Ramp-Hold.

Cone-Fire Basics

Firing Speeds

Cone-Fire operates in Fast, Medium, or Slow speed. The instructions that follow will show you how to select speed.

To view the firing segment of a cone-fire, press **5** during firing (See "Present Status", page 8). The segment number will appear (see left column in the following charts), informing you of how far the firing has progressed.

Fast (1)

Consider Fast for overglazes, decals, china paint, or small, thin-walled ceramic greenware.

Cone-Fire Fast Firing Schedule

Segment in "Present Status"	Actual Segment	Rate of Firing Schedule
5	-	Pre-Heat (if any)
6	1	570° F/hour until the last 250° F
7	2	200° F/hour during the last 250° F

Medium (2)

Use Medium for larger slip-cast pieces or more tightly loaded kilns.

Cone-Fire Medium Firing Schedule

Segment in "Present Status"	Actual Segment	Rate of Firing Schedule
4	-	Pre-Heat (if any)
5	1	110° F/hour until 250° F
6	2	400° F/hour until the last 250° F
7	3	120° F/hour during the last 250° F

Slow (3)

Use Slow for hand-thrown or heavily cast pieces, stoneware, and porcelain.

Cone-Fire Slow Firing Schedule

Segment in "Present Status"	Actual Segment	Rate of Firing Per Hour
2	-	Pre-Heat (if any)
3	1	80° F/hour to 250° F
4	2	250° F/hour until temperature reaches 950° F
5	3	110° F/hour until temperature reaches 1100° F
6	4	225° F/hour until the last 200° F
7	5	90° F/hour until the last 250° F
8	6	150° F/hour, cooling down to 1000° F

Hold

Cone-Fire "Hold" heat-soaks the ware at the end of the firing. Without Hold time, the kiln shuts off after it reaches the cone temperature. With Hold time, the kiln maintains the cone temperature for the period you specify. Hold time helps even out the temperature throughout the kiln. It also helps the heat to penetrate completely into the clay. Rapid firing is like cooking: the turkey will be done

on the outside but not on the inside. Hold helps glaze absorb china paint. It helps to heal glaze defects such as bubbles. A little hold time can yield dramatic results.

CAUTION: Too much hold time can overfire your ware and burn out colors.

One way to add Hold time without over-firing is to fire to one cone cooler than needed. Then add enough hold time to bend the next hotter cone. Hold time needed will vary. As a rule of thumb, one hour of hold = one cone of heat work.

Example: to fire to cone 05½, program Cone-Fire for 05 and add 30 minutes of hold time.

Watch the pyrometric shelf cones through the peephole. Press **STOP** when the correct shelf cone bends, noting how much Hold time was needed. Program that much Hold time the next time you fire the same type of ware loaded to the same capacity. You can hold for up to 99 hours and 99 minutes.

You will learn by experiment with ceramics. Hold is one more tool to experiment with.

Cone-Fire Programming

Use these instructions for your first firings. Later you may prefer "Cone-Fire Quick Reference".

As the RTC 1000 prompts for cone, speed, etc., values entered for the last firing will appear. To use these values again, press **ENTER**.

To fire without Delay or Alarm: Follow steps 1-6 below. Then from **IdLE** press **START** twice.

1. Apply power to the kiln
2. **ErrP** will appear. Press **ENTER**. **IdLE** will appear.
3. Press **ENTER** then 1. **ConE** will appear. Enter cone number. (If **----** appears instead of **ConE**, your controller uses Ramp-Hold only.)
4. Press **ENTER**. **SPd** will appear. Enter speed: Fast (1), Medium (2), Slow (3).
5. Press **ENTER**. **HLd** will appear. Enter hold time, if any, in hours and minutes (i.e. 12 hours and 30 minutes = 12.30).
6. Press **ENTER**. **IdLE** will appear.
7. To set alarm, press **ENTER** then 7. **ALAr** will appear. Enter alarm temperature. (Enter **9999** to turn alarm off.) Then press **ENTER**.
8. To set delay fire, press **ENTER** then 3. **dELA** will appear. Enter delay time in hours and minutes (i.e. 12 hours and 30 minutes = 12.30). Press **ENTER**. (Delay zeroes out after each firing.)
9. To start program, press **ENTER** twice. **-On-** will appear, then time remaining until start. To stop the program during fire, press **STOP**.

Pre-Heating the Ware

Moist greenware can explode during firing. This happens when the moisture in the clay turns to steam rapidly and cannot easily escape. The RTC 1000 "Pre-Heat" feature dries the ware at low temperature before the moisture can turn to steam.

Pre-Heat is necessary when firing thick greenware, such as stoneware. It may also be necessary in humid weather, which inhibits drying. If possible, however, avoid using Pre-Heat to dry greenware. If the greenware feels damp or cool when you touch it to your cheek, dry it longer before firing. Use a dehumidifier in humid weather. Drying greenware in the kiln tends to rust the kiln.

***TIP:** During Pre-Heat, vent the lid. Otherwise the firebricks will absorb moisture, leading to rust behind the stainless steel case. Moisture in the firebrick will also slow the kiln to a crawl when firing begins.*

Venting the lid during Pre-Heat is so important that some ceramists use the extended vent position or even leave the lid open. If you do this, you must be near your kiln at the end of Pre-Heat to lower the lid.

Pre-Heat raises the temperature 60°F/33°C per hour to 200°F/93°C. Then it holds at 200°F/93°C for the time you specify. Pre-Heat works in Cone-Fire only. After Pre-Heat is finished, the kiln will automatically begin firing to the cone you have selected. Pre-Heat zeroes out after each firing.

After entering the cone number, speed, etc., in the Cone-Fire program, activate Pre-Heat as follows. Then begin firing.

1. Press **ENTER**
2. Press **0** repeatedly until **PrHt** appears.
3. Press **ENTER**. **HLd** alternating with **00.00**.
4. Enter Pre-Heat hold time in hours and minutes (i.e. 1 hour 30 minutes = 01.30).
5. Press **ENTER**. **CPL** will appear, then **IdLE**.

AOP

The optional "AOP" (Auxiliary Output) is an extra output on the controller. The AOP can be used to power a relay to control a kiln vent or other appliance. If your kiln is equipped with AOP, **AOP** will appear in Cone-Fire after **HoLD**. (If **AOP** does not appear in the display, your kiln is not equipped with AOP.)

When set to OFF, the AOP receives power during the Cone-Fire firing. At the end of the firing, the AOP shuts off.

When set to ON, the AOP remains powered during both Cone-Fire firing and cooling. It shuts off after the kiln cools to 150°F/66°C.

***TIP:** For slow cooling in Cone-Fire, select AOP OFF.*

Adjusting AOP in Cone-Fire

1. After programming Cone, Speed, and Hold, **AOP** will appear, alternating with **On** or **OFF**.
2. To Change the setting, press **1**, then **ENTER**. **CPL** will appear, followed by **IdLE**.

Advanced Cone-Fire

Built-in Cone Table

For your convenience, the controller can look up a pyrometric cone temperature. Do not be concerned if your kiln's cone shut-off temperature differs from the cone table temperature. The shut-off temperature varies with the firing speed.

1. From **IdLE**, touch **ENTER** then **9**. **ConE** will appear, then the cone currently programmed in Cone-Fire Mode.
2. Enter the pyrometric cone number you are looking up. Then touch **ENTER**. The display will show the cone temperature. If you enter a non-existent cone number, the display will show **ConE**, ready for you to enter a different cone number.

Cone temperatures displayed are for self-supporting cones fired at a rate of 108°F during the last hour.

Firing History in Cone-Fire

When the kiln fires to completion, **CPLt** will flash, alternating with total firing time in hours and minutes. To view the final temperature the kiln reached, press **ENTER**. **IdLE** will appear. Press **ENTER** then **6** (Program Review). Final firing temperature will display along with the cone, speed, and hold.

Fine-Tuning Shelf Cones With Cone Offset (CnoS)

Sometimes the pyrometric cone programmed in Cone-Fire does not match the bending of the cone on the kiln shelf. Using "Cone Offset" you can adjust to fire hotter or cooler.

IMPORTANT: Cone Offset adjusts the firing temperature individually for each pyrometric cone number. Adjusting one cone has no effect on the other cones. To adjust all the cones equally, use "Thermocouple Offsets", page 8.

For instance, the controller fires shelf cone 018 to a perfect six o'clock bend. But at cone 6, the shelf cone over-fires. Using Cone Offset, you could lower cone 6 firing temperatures without affecting the perfect results you are getting at cone 018.

***TIP:** Before using Cone Offset, check that the thermocouple is protruding into the firing chamber by at least 1-1/2" to 2". Sometimes bumping a shelf against a thermocouple pushes it out of the firing*

chamber, thereby preventing accurate temperature readings.

How to Use Cone Offset

1. From **IdLE**, press **ENTER**.
2. Press **0** until **CnoS** appears.
3. Press **ENTER**. **ConE** will appear, alternating with last cone number entered in Cone-Fire. Enter the new cone number.
4. Press **ENTER**. **°FOS** (or **°COS** for Celsius) will appear, alternating with **9000** or an adjustment number.
5. Enter adjustment number (see chart). Then press **ENTER**. **CPL** will appear, then temperature and **IdLE**.

You can raise or lower firing chamber temperature for each cone from 1-50°F/1-28°C. Place 00 in front of the number to make the kiln fire hotter. Place 90 in front to make it fire cooler.

The following chart contains seven examples of Cone Offsets. Program any temperature in the 01-50°F/1-28°C range, hotter or cooler, using these examples as a guide.

Cone Offset Examples, °F

0001	Kiln will fire 1°F Hotter
0030	Kiln will fire 30°F Hotter
0049	Kiln will fire 49°F Hotter
0000 or 9000	No Adjustment
9005	Kiln will fire 5°F Cooler
9040	Kiln will fire 40°F Cooler
9049	Kiln will fire 49°F Cooler

* Cone Offset works in °C the same as in °F. In the above examples, replace °F with equivalent °C.

Once you enter a Cone Offset number, Cone-Fire will remain adjusted to that number for that cone until you change it again. Keep a written record of Cone Offset Adjustments.

Ramp-Hold

Ramp-Hold fires in segments. Each segment has an end temperature, a degrees per hour rate to reach that temperature, and a hold time.

Ramp-Hold Basics

User Programs

When you enter Ramp-Hold mode, the first prompt to appear is **USEr**, meaning, "Select a User Program". A user program is a firing schedule stored in memory.

It includes:

1. Number of segments needed
2. Rate (how fast temperature changes in degrees per hour) for each segment
3. Target temperature for each segment
4. Hold, if any, for each segment
5. Alarm temperature, if any

The controller can retain six user programs in memory even when power to the kiln is turned off.

If using Ramp-Hold for the first time, press **1** when **USEr** appears. Your first firing will be stored as User Program #1.

Each time you store another program, select the next available number, such as 2, at the **USEr** prompt. Write down the firing profiles of your User Command.

When you use a stored program, select the program number at the **USEr** prompt. Press **ENTER**. If there are no changes to the program, press **STOP**. **CPL** will appear, then **IdLE**. The controller is ready to fire your selected program.

Segments

A "Segment" fires to a target temperature. It includes a rate and, if needed, a hold. Every time you need to change firing speed or hold a temperature, add another segment. You have up to eight segments available in a User Program. You don't have to use all eight segments – only the number needed per firing. Often one segment is all you will need.

For complex firings, Ramp-Hold can be fired in 16 segments instead of the standard eight.

Rate

Each segment must include a rate, programmed as degrees of temperature change per hour. One way to figure rate is to divide firing temperature by number of hours needed to fire. Maximum rate is 9999. When you enter 9999, the controller will heat as fast as your furnace or kiln is capable.

If you are not sure about how fast to fire, remember the old firing adage: "When in doubt, slow it down."

Hold

"Hold" in Ramp-Hold maintains the target temperature of a segment for the time you specify. Hold gives the temperature time to become more even throughout the kiln. Hold can be used in either heating up or cooling down segments.

Wearing firing safety glasses, watch the pyrometric cones on the shelf near the end of the firing. When the shelf cone bends, note the hold time. The next time you fire the same type of ware loaded to the same capacity, program that amount of hold time.

Ramp-Hold Programming

Use these instructions for your first firings. Later you may prefer “Ramp-Hold Quick Reference”

As the program prompts for segments, rate, temperature, etc., you will see values from the last firing. To use these again, press **ENTER**. To control cooling, set the segment to a lower temperature than that of the preceding segment.

To fire without a timed Delay: Follow steps 1 through 8, then press **START** twice.

1. Apply power to the kiln. **ErrP** will appear. Press **ENTER**. **IdLE** and kiln temperature will appear.
2. Press **ENTER** then **4**. **USEr** will appear. Enter a number from 1-6 for the stored program desired.
3. Press **ENTER**. **SEGS** will appear. Enter number of segments needed.
4. Press **ENTER**. **rA 1** will appear. Enter firing rate for segment 1 (temperature change per hour: from 1° - 9999°).
5. Press **ENTER**. **°F 1** (or **°C 1**) will appear. Enter the target temperature of segment 1.
6. Press **ENTER**. **HLd1** will appear. Enter segment 1 hold time in hours/minutes (i.e. 12 hours and 30 minutes = 12.30). No hold = 00.00.
7. Press **ENTER**. Continue entering values for all segments.
8. Press **ENTER**. **ALAr** will appear. Enter alarm temperature. (Enter **9999** to turn alarm off.) Then press **ENTER**. **CPL** will appear, then **IdLE**.
9. To set Delay Fire, press **ENTER** then **3**. **dELA** will appear. Enter delay time in hours/minutes (i.e. 12 hours and 30 minutes = 12.30). Then press **ENTER**. (Delay zeroes out after each completed firing). **CPL** will appear, then **IdLE**.
10. To start program, press **ENTER** twice. **-On-** will appear, then kiln temperature. If delay was programmed, **-On-** will appear then time remaining until start.

To stop the firing, press **STOP**. When program fires to completion, **CPLt** will appear. Press **STOP**. **IdLE** will appear, alternating with cool-down temperature. To shut off the alarm when it sounds during a firing press **ENTER**.

AOP

The optional “AOP” (Auxiliary Output) is an extra output on the controller. The AOP can be used to power a relay to control a kiln vent or other appliance. If your kiln is equipped with AOP, **AOP** will appear in Ramp-Hold after **SEG**. (If **AOP** does not appear in the display, your kiln is not equipped with AOP.) In Ramp-Hold, AOP can be turned on or off for each segment.

Adjusting AOP in Ramp-Hold

1. After selecting the User Program and number of segments, **AOP1**, alternating with **On** or **OFF**, will appear.
2. To change the setting, press **1**, then **ENTER**. Continue entering rate, temperature, hold, etc. for segment 1. As you continue programming, turn AOP on or off in each segment.

Advanced Ramp-Hold

Segments for Controlled Cooling

For controlled cooling, program a segment to a lower temperature than that of the preceding segment.

Skip Segment

You may need to skip a segment in Ramp-Hold. For instance, you are firing to cone 05 for the first time. You program the last segment to soak for 30 minutes at 1850°F. (This is a few degrees below cone 05.) You are not sure at what temperature the cone will bend during this firing.

At 1850°F, the alarm beeps, alerting you to check the witness cone on the shelf. You look into peephole every few minutes to check the cone. After a 10-minute hold, the shelf cone 05 bends to maturity. Using “Skip Segment”, the controller begins a cool-down segment. Skip Segment stops the current segment and starts the next segment.

Skip Segment works only during firing and only in Ramp-Hold, not Cone-Fire. To skip a segment, press **9**. **SStP** will appear. If you change your mind and don't want to skip that segment, do nothing and the firing will continue as it was. If you still want to skip the segment, press **ENTER**. **rA** will appear along with the segment number you just skipped to.

Press 5 (“Present Status”) if you are not sure which segment the firing has reached. Then skip the segment.

16 Segment Firing (16-S)

Sixteen segment firing combines Ramp-Hold user programs 5 and 6 into one continuous firing. You can use all 16 segments, or only a few segments from each program. Program 5 will fire first, then program six.

1. Press **ENTER**, then **4**. **USEr** will appear, alternating with the last user program entered.

- Press **5** (user program 5), then **ENTER**. Using Ramp-Hold instructions, enter the values for all segments needed in program 5.
- IdLE** and temperature will display after program 5 is entered. From **IdLE**, press **ENTER**, then **4**.
- USEr** will appear, alternating with 5. Press **6** (user program 6), then press **ENTER**. As before with program 5, enter the values for all segments needed in program 6.
- IdLE** will appear after program 6 is entered. Press **ENTER**, then **PROGRAM REVIEW**. Make sure all values for user program 6 are correct. After reviewing the program, **IdLE** will appear.
- From **IdLE**, press **ENTER**, then **4**. **USEr** will appear, alternating with 6. Press **5**, then **ENTER**.
- Press **STOP**. **CPL** will appear, then **IdLE** and temperature. Program 5 is now selected in Ramp-Hold.
- From **IdLE**, press **ENTER**, then **0** repeatedly until **16-S** appears. Press **ENTER**.
- OFF** or **On** will appear. Press **1** to change **OFF** to **On**. **On** will appear. Press **ENTER**. **CPL** will appear, then **IdLE**.
- Begin firing by pressing **ENTER** twice. **16-S** appears under **MENU** only after user program 5 has been selected in Ramp-Hold.

*When you use Program Review for a 16 segment firing, user program 5 will appear. Then **16-S**, **On**, to confirm that your program is the 16 segment. However, the values for user program 6 will not appear in Program Review.*

Additional Features

Selecting °F or °C (CHG°)

The controller operates in your choice of °F or °C temperature. In °C display, a lighted dot appears in the lower right. In °F, it disappears. To switch from °F to °C or vice versa:

- From **IdLE**, press **ENTER**.
- Press **0** repeatedly until **CHG°** appears.
- Press **ENTER**. or **°C** will appear.
- To change, press **1**.
- Press **ENTER**. **CPL** will appear, meaning the change has been completed.

°F/°C Temperature Conversion Formula

Below are formulas for converting temperature between °F and °C. Converting a firing rate requires a different formula than firing temperature:

Firing Temperature

(i.e. “Fire to 1600°F.” $1600^{\circ}\text{F} = 871^{\circ}\text{C}$)

$$(^{\circ}\text{C} \times 1.8) + 32 = ^{\circ}\text{F}$$

$$(^{\circ}\text{F} - 32) \div 1.8 = ^{\circ}\text{C}$$

Firing Rate and Temperature Change

(i.e. “Fire at 200°F per hour” or “Fire 200°F hotter”)

$$200^{\circ}\text{F} = 111^{\circ}\text{C}$$

$$^{\circ}\text{C} \times 1.8 = ^{\circ}\text{F}$$

$$^{\circ}\text{F} \div 1.8 = ^{\circ}\text{C}$$

Delay Fire

The Delay Fire programs the kiln to begin firing later. Use it to adjust the firing to suit your schedule or to take advantage of lower electric rates at night.

It zeroes out after each completed firing. To set the Delay, follow earlier instructions for entering the Cone-Fire or Ramp-Hold firing program. Then press **ENTER**, then **3**. Enter the delay time in hours/minutes. (i.e. 12 hours and 30 minutes = 12.30). To begin firing, press **ENTER** twice.

***WARNING:** Never leave your kiln unattended near the end of a firing. We cannot guarantee your kiln against overfiring even though the controller is automatic. The operator assumes full responsibility for shutting the kiln off at the proper time.*

Temperature Alarm

The alarm beeps when a preset temperature is reached. Use the alarm to alert you to:

- Lower the lid from venting position.
- Check the witness cone near shut-off time.
- Check the fusing or slumping of glass.
- Remove the knife blade from the furnace at the end of heat training.

You can enter only one alarm temperature at a time. However, after the alarm beeps, you can set the alarm for another temperature as many times as you want during the firing. You can enter a higher or lower temperature than the current temperature.

Setting the Alarm From Idle

- From **IdLE**, press **ENTER** then **7**. **ALAr** will appear alternating with the last alarm temperature entered.
- Enter desired alarm temperature. Then touch **ENTER**. **IdLE** will appear. (Enter **9999** to turn alarm off.)

When the alarm sounds, shut it off by **ENTER**. (Do not press **STOP** to turn off the alarm.) If the alarm sounds as soon as the furnace or kiln begins firing, it is because the alarm was set to **0000**, or any temperature below room temperature.

Setting Alarm During Firing

- The alarm beeps while the kiln is firing. Press **7**.
- Enter the new alarm temperature.

3. Press **ENTER**. The kiln will continue firing.
***CAUTION:** If you touch 7, enter a new temperature, and forget to press **ENTER**, the firing will stop and the kiln will begin to cool down. You must press **ENTER** after entering the new alarm movement.*

Add Time

Pressing the "ADD TIME" key during a hold period adds 5 extra minutes to the hold period. To add time, press "ADD TIME", "tME" will be displayed, then the temperature alternating with the new hold time.

Present Status: Current Segment and Circuit Board Temperature

"Present Status" displays the current segment of a firing and temperature of the circuit board.

Knowing which segment you are in is especially useful for firings with both heating-up and cooling-down segments. Present Status works with both Cone-Fire and Ramp-Hold. (See Cone-Fire firing schedules, page 3)

To use present Status, press **5** during a firing. The following information will display momentarily. Then normal temperature display will return:

1. Ramp (**RA**) or Hold (**HLd**) followed by segment number.
2. Local Set Point, the temperature the controller is trying to reach to maintain the correct rate.
3. Circuit Board Temperature

High temperatures in the switch box can damage the controller circuit board. The circuit board is rated for 155°F/68°C maximum operating temperature. Maximum temperature for rated accuracy is 125°F/52°C. The controller board can operate safely at 155°F/68°C, although 125°F/52°C is preferable. If necessary, exhaust hot air from the room to lower board temperature. When firing several kilns, position them at least three feet apart to allow adequate air circulation.

Checking Circuit Board Temperature from IdLE

1. Press **ENTER**.
2. Press **0** repeatedly until **bd t** (board temperature) appears.
3. Press **ENTER**. The board temperature will appear, followed by **StOP**, and then the firing chamber temperature.

Power Failures

The RTC 1000 handles a power failure in two ways:

1. A **PF** display, alternating with firing temperature, means firing was interrupted by a brief power failure. The firing will continue. **PF** is only to inform you of a brief power failure. Press **ENTER**, and normal temperature display will return.

2. A steady **ErrP** display means firing was interrupted by an extended power failure. When **ErrP** appears, the kiln heating elements will stay shut off. The following three situations cause **ErrP** messages:
 - a) The power failure lasted longer than 1 ½ hours.
 - b) The kiln cooled off more than 250°F/139°C while the power was off.
 - c) Cone-Fire mode only: the power failed within 100°F/56°C of the shut-off temperature.

When the **ErrP** power failure message appears, press **ENTER**. The hours fired and temperature reached, before the power failed, will appear followed by **IdLE**.

To resume firing, press **ENTER** twice. The kiln will begin firing again from its present temperature. For example, the kiln reached 1000°F/538°C before power failed. When you turn the kiln back on, the temperature is 700°F/371°C. Firing will resume from 700°F/538°C. You do not need to cool the kiln to room temperature before starting over unless you use witness cones (See next section).

When you resume firing by pressing **ENTER** twice, the controller begins firing again from segment one. If the temperature is already higher than that of segment one, the controller skips to the next segment. When it finds a segment with a higher target temperature, it begins firing in that segment. For this reason, a power failure during a ramping down (cooling) segment can confuse the controller. When you resume firing, the controller will begin firing from a ramping up (heating) segment rather than the ramping down segment.

Firing Ceramics After an Extended Power Failure

1. The firing was interrupted below 100°F/56°C of maturity: Fire the ware again. It is okay to use the same partially fired witness cones, even if they cooled back down to room temperature. As long as the cones did not reach within 100°F/56°C of maturity.
2. The ware fired within 100°F/56°C of maturity: Fire the ware again but do not use same witness cones. Use new ones.

Thermocouple Offset (tCOS)

The thermocouple is the 1/8" diameter rod protruding into the firing chamber. It measures temperature. Thermocouples can "drift" as they age, causing inaccurate temperature readings. (This may be so slight that you won't notice it.) To calibrate the controller to compensate for drift, use "Thermocouple Offset".

***TIP:** Before using Thermocouple Offset, check that the thermocouple is protruding into the firing chamber by at least 1-1/2" to 2". Sometimes bumping a shelf against a thermocouple pushes it out of the*

firing chamber, thereby preventing accurate temperature readings.

Thermocouple Offset for Ceramic Firings

In ceramics, Cone Offset (see page 4) adjusts each pyrometric cone without affecting the other cones. Thermocouple Offset, on the other hand, affects all cones equally, and all Ramp-Hold firings. A 5°F hotter setting in Thermocouple Offset fires everything 5°F hotter.

If you find that all of your cones are consistently under- or over-firing, adjust Thermocouple Offset. If you need to adjust only a particular cone, use Cone Offset.

Calibrating Thermocouple Offset with a Thermocouple Standard or Pyrometer.

A thermocouple standard is a device that calibrates pyrometers and controllers. If you do not have a thermocouple standard, you can calibrate Thermocouple Offset using a calibrated digital pyrometer. One way to calibrate your digital pyrometer is to take it to a heat treater or other location that has a calibrated controller you can trust. Take a reading with your pyrometer. Either zero it out to match the other heat source, or write down the temperature difference between your pyrometer and the reliable source. Store your pyrometer. Use it only for calibrating controllers. Thus, it remains a reliable calibration standard.

Adjust Thermocouple Offset to compensate for any temperature difference between the controller and the calibrated pyrometer or thermocouple standard.

Setting Thermocouple Offset

You can raise or lower firing chamber temperature from 1-50°F/1-28°C. If the kiln is firing too hot, place 90 and 01-50°F/1-28°C. If the kiln is too cool, place 00 before 01-50°F/1-28°C.

The following chart contains seven examples of Thermocouple Offsets. Program any temperature in the 01-50°F/1-28°C range, hotter or cooler, using these examples as a guide.

Thermocouple Offset Examples, °F

0001	Kiln will fire 1°F Cooler
0030	Kiln will fire 30°F Cooler
0049	Kiln will fire 49°F Cooler
0000 or 9000	No Adjustment
9005	Kiln will fire 5°F Hotter
9040	Kiln will fire 40°F Hotter
9049	Kiln will fire 49°F Hotter

* Thermocouple Offset works in °C the same as in °F. In the above examples, replace °F with equivalent °C.

Directions for Thermocouple Offsets:

1. From **IdLE**, press **ENTER**.
2. Press **0** repeatedly until **tCOS** appears.

3. Press **ENTER**. **°FOS** (or **°COS**) will appear, alternating with the current thermocouple offset. (Factory setting is 00.00)
4. Enter the new offset (i.e. 9005). Press **ENTER**. **IdLE** will appear.

*To reset Thermocouple Offset back to 0000, press **ENTER** then **0**. **RSEt** will appear, then press **ENTER**.*

Turning Off Error Codes (ErCd)

The RTC 1000 uses error codes to alert you to firing problems. In certain applications, it may be desirable to turn off some of the error codes.

For instance, error code **Err1** appears when temperature rises slower than 12°F/12°C per hour. (In Ramp-Hold, the temperature is also below the programmed temperature.) **Err1** may interfere when the door of the kiln is opened to remove certain materials, such as enameled pieces or heat-treated steel.

“Error Codes” **ErCd**, when set to OFF, turns off all error codes except **Err6**, **Err8**, **ErrP**, and those dealing with hardware errors.

*During the last 250°F/139°C of a Cone-Fire program, the **Err1** code will become active again even when **ErCd** is turned off.*

Setting Error Codes ON or OFF

1. Press **ENTER** from **IdLE**.
2. Press **0** repeatedly until **ErCd** appears.
3. Press **ENTER**. **On** or **OFF** will appear. Press **1** to change the setting.
4. Press **ENTER**. **CPL** will appear, followed by temperature and **IdLE**.

RSEt (from **MENU** key) can turn on error codes

Menu Quick Reference List

RSEt Sets the Thermocouple Offset to 0 and turns error codes on; page 9.

PrHt Used in Cone-Fire only; Pre-Heat; page 4.

Id Identifies the kiln for interface with a personal computer. Used for *K.I.S.S.* (Kiln Interface Software System)

CnOS Used in Cone-Fire only: Cone offset; changes the temperature shut-off of individual cones; page 4.

ChG° changes temperature read-out between °C and °F; page 7

ErCd Error codes: Turns errors off. Designed for applications where the furnace door is opened at high temperatures, such as heat-treating; page 9.

tCOS Thermocouple Offset: calibrates the thermocouple read-out; page 8.

Bd t Board temperature: shows the temperature of the circuit board; page 8.

RTC 1000 Cone-Fire Quick Reference

After you press the key(s) in the left column, the message to the right will appear. If after pressing **ENTER**, then **1**, only four horizontal lines appear, your controller does not have Cone-Fire.

NO DELAY FIRE, NO ALARM. IF ALARM SOUNDS DURING FIRING, PRESS ENTER

KEYS TO PRESS	DISPLAY
Apply power to kiln	ErCd
ENTER	IdLE
ENTER	----
1	CO nE
Cone # of Choice	05 Displays cone #
ENTER	SPd
1 (Fast), 2 (Med.), or 3 (Slow)	FASt, MEd, or SLO
ENTER	HLd
Hold time (if any)	00.00 Displays hold time (if any)
ENTER	CPL IdLE and flashing temp.
ENTER	----
ENTER	-On-

RTC 1000 Ramp-Hold Quick Reference

After you press the key(s) in the left column, the message to the right will appear. If alarm sounds during a firing, press ENTER.

KEYS TO PRESS	DISPLAY
Apply power to kiln	ErrP
ENTER	IdLE
ENTER	- - - -
4	USEr / 1 etc.
Select program 1-6	1 etc. Displays # entered
ENTER	SEG
Number of segments needed	1 etc. Displays # entered
ENTER	rA 1
Temp. change per hour	0200 etc. Displays temp.
ENTER	°F 1
Final temperature, seg. 1	2000
ENTER	HLd1
Hold time (if any)	00.00 (or hold time)
ENTER	-On-
<u>Repeat for number of segments desired</u>	
ENTER	ALAr (Alarm temp.)
Alarm temp (OFF= 9999)	2000 etc. Displays temp
ENTER	CPL IdLE and flashing temp.
ENTER	-On-
<u>SELECT AND FIRE A STORED USER PROGRAM; NO DELAY FIRE</u>	
Apply power to kiln	ErrP
ENTER	IdLE
ENTER	- - - -
0	rECL
ENTER	USEr / 1 etc. (select program)
1 through 6	1 etc. Displays selected program
ENTER	CPL
ENTER, ENTER	-On-
<u>Kiln is now firing. (See separate program review instructions.)</u>	

Appendix A: Edit-on-the-Fly

Programming "on the fly" is the ability to make changes to the program while the kiln is firing. Programming on the fly allows great flexibility but there are precautions that must be taken into consideration, see Appendix A: Programming Cautions.

Programming

Programming on the fly allows for changes to be made only to the current segment being fired. You can change the rate of rise, the soak temperature, the hold time, or any combination of these three. To check the current segment, press the "5" key, "PRESENT STATUS". If you are firing the segment you want to change, then press the "4" key, RAMP HOLD. rA followed by the current segment number will be displayed alternating with the current rate of rise. Make changes if desired and press ENTER or just press ENTER to proceed to the soak temperature. The soak temperature and the hold time can be changed similarly if desired.

After pressing ENTER for the hold length the controller will save the changes and return to firing. **These changes are permanent and they will be part of the program for all subsequent firings.**

If there is no key press for forty seconds after entering programming on the fly, the controller will return to the current firing without any changes.

Either after the final ENTER key press or if there is no key press, the controller returns to the ramp of the current segment. If you were in a hold, the controller will ramp to the hold again and rerun the entire hold period.

Following is a brief example of utilizing programming on the fly.

The RTC 1000 controller is currently in segment two that has the following data:

Rate of rise	500°F/hr
Soak temperature	1250°F
Hold time	10 minutes

The controller has not yet entered the hold for this segment but it is nearing the 1250°F soak temperature. The operator wishes to increase the soak temperature by 15° to 1265°F.

Pressing the RAMP HOLD key (4) brings up programming on the fly. Since the rate of rise is not going to be changed the ENTER key is pressed to skip to the soak temperature. The controller is now alternating between °F 2 and 1250. Key in 1265 and press ENTER. Press ENTER again since no change in the hold time is desired. These changes affect this firing and the changes are stored to the program for future firings.

KEYPRESS	DISPLAY	NOTES
RAMP HOLD	rA 2/0500	Begins the programming on the fly operation.
ENTER	°F 2/1250	No change made to rate of rise.
1	0001	Making changes to the soak temperature.
2	0012	
6	0126	
5	1265	
ENTER	HLd2/00.10	Soak temperature updated to 1265°F.
ENTER	Current temperature	No changes made to hold length and programming on the fly complete.

Programming Cautions

This appendix lists situations that could arise from utilizing the programming on the fly feature. There are certain instances where programming on the fly could cause undesired effects or error codes. If you are unsure of how a change will affect the firing it is safer to not make any changes.

Continuous operation of the elements

If the kiln elements are heating when you enter programming on the fly they will remain on during the entire programming procedure. This means that the kiln will be heating at full power during the time you program. If no key is pressed and the kiln will heat at full power until the 40 second timeout period is complete.

Changing direction of ramping

It is possible to have the kiln go from an up ramp to a down ramp with the proper changes in the program. Although this could be the desired effect it is included as a programming caution to warn of the potential for its occurrence.

Error D (Errd) due to changing soak temperature

It is possible to alter the soak temperature and cause the controller to display Errd. Errd occurs whenever the kiln temperature is more than 100°F above the traveling set point. If the controller soak temperature is decreased to a value more than 100° below the current kiln temperature, Errd may occur.

Error 2 (Err2) or Error 3 (Err3) from changing soak temperature

Either Err2 or Err3 may occur if after altering the soak temperature, the kiln temperature deviates from the travelling set point by more than 50°F.